



## UNDERCABINET EDGE 1 400 800 WITH 600 MODULE WHITE

Item number: 1590205

Basin vanity unit with SmoothOpen™ drawer system, a combination of push-open and soft-close in one. Non-slip mats in the drawers to make cleaning easier are included. Reinforced with an aluminium frame on the front edge. Supplied pre-assembled. The top drawer has a U design, leaving space for the water trap. Add a PUM water trap designed for vanity units, 126 56 00. Prepared for both floor and wall drains. Adjustable hanging brackets. Drawer lighting, power socket and handles available as an option.



### DETAILED INFORMATION

| Item number                   |               | Material and surface treatment  |        |
|-------------------------------|---------------|---------------------------------|--------|
| RSK                           | 8907735       | Color                           | White  |
| EAN                           | 7330027113814 | Packaging dimensions and weight |        |
| Standards and classifications |               | Package height(m)               | 0,510  |
| ETIM                          | EC011382      | Package width (m)               | 1,600  |
| Product dimensions and weight |               | Package depth(m)                | 0,515  |
| Net weight (kg)               | 43            | Package weight(kg)              | 45,500 |

### CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.