



UNDER CABINET EDGE 1000 ANTHRACITE

Item number: 1590021

The Edge vanity unit in anthracite white from Hafa is a stylish choice with slim lines, mitred corners and exclusive materials. The well-considered design creates an elegant expression that enhances the entire bathroom. The integrated SmoothOpen™ system combines push-open and soft-close for smooth and quiet use.

The unit is delivered fully assembled with drawer mats that help keep things organised, add a considered feel to the interior and make cleaning easy. Complete with a worktop and a countertop basin, or with an inset washbasin to complete the overall look. Handles are available as an optional extra for those who want to customise the unit to suit their own style.

25^{year}
WARRANTY

DETAILED INFORMATION

Item number		Material and surface treatment	
NOBB	51456606	Main material	Chipboard, MDF
RSK	8906599	Front material	MDF
EAN	7330027103358	Body material	Chipboard
Stocked article	Yes	Surface treatment	Lacquered
Standards and classifications		Surface finish	Matt
Sunda Hus	No	Color	Anthracite
Säker Vatten	Yes	Packaging dimensions and weight	
ETIM	EC011382	Package height(m)	0,510
Product dimensions and weight		Package width (m)	1,060
Width	1000	Package depth(m)	0,515
Depth (mm)	456	Package weight(kg)	34,500
Height (mm)	450	Miscellaneous	
Net weight (kg)	32	Suspension type	Justerbara upphängningsbeslag med väggskena
		Opening function	SmoothOpen

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.