



UNDER CABINET EDGE WHITE 2000D

Item number: 1590211

The Edge vanity unit in matt white from Hafa is a stylish choice with slim lines, mitred corners and exclusive materials. The well-considered design creates an elegant expression that enhances the entire bathroom. The integrated SmoothOpen™ system combines push-open and soft-close for smooth and quiet use.

The unit is delivered fully assembled with drawer mats that help keep things organised, add a considered feel to the interior and make cleaning easy. Complete with a worktop and a countertop basin, or with an inset washbasin to complete the overall look. Handles are available as an optional extra for those who want to customise the unit to suit their own style.

25^{year}
WARRANTY

DETAILED INFORMATION

Item number		Material and surface treatment	
NOBB	60941914	Main material	Chipboard, MDF
EAN	7330027185897	Front material	MDF
Standards and classifications		Body material	Chipboard
Sunda Hus	No	Surface treatment	Lacquered
ETIM	EC011382	Color	White
Product dimensions and weight		Packaging dimensions and weight	
Width	2000	Package height(m)	0,515
Depth (mm)	456	Package width (m)	1,060
Height (mm)	450	Package depth(m)	1,020
Net weight (kg)	64	Package weight(kg)	68,000
		Miscellaneous	
		Suspension type	Justerbara upphängningsbeslag med väggskena
		Opening function	SmoothOpen

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.