



SIDE MODULE SHAPE PUSH WHITE 300

Item number: 1390301

Combine your vainty cabinet with Hafa Shape side cabinet for fither widths and configurations. Inside the cabinet is a shelf. The side module and its hatch can be mounted on right or left hand side. Choose between SoftClose or push-open hatch. For your SoftClose option, choose one of our handles or knobs.



DFTAILED INFORMATION

| Item number | | Material and surface treatment | |
|----------------------------------|---------------------|---------------------------------|--|
| NOBB | 54473633 | Main material | Moist resistant MDF, Moist |
| RSK | 8907534 | Front material | resistant chipboard |
| EAN | 7330027109831 | Front material | Moist resistant MDF |
| Chandands and also if is at in a | | Body material | Moisture resistant chipboard |
| Standards and classifications | EC011382 | Surface treatment | Lacquered |
| ETIM | | Surface finish | Matt |
| Product dimensions and weight | | Color | White |
| Width | 300 | Packaging dimensions and weight | |
| Depth (mm) | 453 | Package height(m) | 0,595 |
| Height (mm) | 535 | Package width (m) | 0,360 |
| Hole spacing, handle (mm) | Center, CC96, CC128 | 3 , , | |
| Net weight (kg) | 13 | Package depth(m) | 0,520 |
| Net Weight (Ng) | 15 | Package weight(kg) | 13,300 |
| | | Miscellaneous | |
| | | Suspension type | Justerbara upphängningsbeslag med väggskena |

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.

Opening function

Push-to-open