



HIGH CABINET STORE COMPACT PUSH WHITE

Item number: 1390461

Tall cabinet with shallow dimensions. Choose between push-open doors without handles and soft-close doors with handles of your choice. The doors can be fitted on the right or left side, so you can decide which side the door should open. Inside the cabinet there are height-adjustable glass shelves with shelf rests that lock them securely in place.



DETAILED INFORMATION

Item number		Material and surface treatment	
NOBB	54473913	Main material	Chipboard, MDF, Glass
RSK	8938813	Front material	MDF
EAN	7330027110110	Body material	Chipboard
Stocked article	Yes	Surface treatment	Lacquered
Standards and classifications		Surface finish	Matt
ETIM	EC010013	Color	White
BVB id	178063	Packaging dimensions and weight	
Product dimensions and weight		Package height(m)	1,610
Width	400	Package width (m)	0,460
Depth (mm)	200	Package depth(m)	0,250
Height (mm)	1550	Package weight(kg)	27,500
Hole spacing, handle (mm)	Knopp, CC96, CC128	Miscellaneous	
Net weight (kg)	21	Suspension type	Justerbara upphängningsbeslag med väggskena
Left/right model	Vändbar	Opening function	Push-to-open

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.