

TVÄTTSTÄLLSKÅP EDGE SMOKED OAK 600 WITH BASIN

Item number: 1590221

The Edge vanity unit in smoked oak from Hafa is a refined choice with slim lines and premium materials. An inset washbasin with rectangular bowl is included.

The integrated SmoothOpen™ system combines push-to-open and soft-close for smooth, quiet operation.

The unit is delivered fully assembled with integrated drawer mats that keep things organised, create a considered interior feel and make cleaning easy. Optional handles allow you to personalise the look while retaining the practical soft-close function.

25 year WARRANTY

FSC www.fsc.org
The mark of responsible forestry
FSC® C220675

DETAILED INFORMATION

Item number	
NOBB	60941923
EAN	7330027186030
Standards and classifications	
Sunda Hus	No
ETIM	EC011382
Product dimensions and weight	
Width	610
Depth (mm)	465
Height (mm)	470
Hole spacing, handle (mm)	0, 128, 160
Net weight (kg)	40,5

Material and surface treatment	
Main material	Chipboard, Porcelain
Front material	Chipboard
Body material	Chipboard
Surface treatment	Lacquered venér
Color	Smoked oak
Packaging dimensions and weight	
Package height(m)	0,710
Package width (m)	0,660
Package depth(m)	0,520
Package weight(kg)	43,000
Miscellaneous	
Suspension type	Justerbara upphängningsbeslag med väggskena
Opening function	SmoothOpen

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.