

HIGH CABINET STORE PUSH WHITE

Item number: 1390421

Tall cabinet with generous depth. Choose between push-open doors without handles and soft-close doors with handles of your choice. The doors can be fitted on the right or left side, so you can decide which side the door should open. Inside the cabinet there are height-adjustable glass shelves with shelf rests that lock them securely in place.

25 year WARRANTY

Quality

B

DETAILED INFORMATION

Item number	
NOBB	54473773
RSK	8938799
EAN	7330027109978
Stocked article	Yes
Standards and classifications	
ETIM	EC010013
BVB id	178063
Product dimensions and weight	
Width	400
Depth (mm)	350
Height (mm)	1550
Hole spacing, handle (mm)	Knopp, CC96, CC128
Net weight (kg)	28
Left/right model	Vändbar

Material and surface treatment	
Main material	Chipboard, MDF, Glass
Front material	MDF
Body material	Chipboard
Surface treatment	Lacquered
Surface finish	Matt
Color	White
Packaging dimensions and weight	
Package height(m)	1,610
Package width (m)	0,460
Package depth(m)	0,410
Package weight(kg)	35,500
Miscellaneous	
Suspension type	Justerbara upphängningsbeslag med väggskena
Opening function	Push-to-open

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.