

HIGH CABINET GO LIGHT OAK

Item number: 1580308

The Go high cabinet from Hafa is a spacious unit offering generous storage. It features a veneered finish and is available in several colours. Inside are five shelves; one fixed wooden shelf and four height-adjustable glass shelves, making the cabinet easy to clean and flexible to organise.

The cabinet has a soft-close door with an integrated handle. The fully assembled unit is mounted easily on a wall rail with adjustable fittings, making installation straightforward even for one person. The door can be mounted left- or right-handed.Also available in a shallower depth, ideal for smaller bathrooms or where you want to save floor space. Power socket available as an option.

DETAILED INFORMATION

Item number	
NOBB	60941880
EAN	7330027183589
Standards and classifications	
Sunda Hus	No
ETIM	EC010013
Product dimensions and weight	
Width	400
Depth (mm)	350
Height (mm)	1555
Net weight (kg)	30
Left/right model	Vändbar

Material and surface treatment	
Main material	Chipboard
Front material	Chipboard
Body material	Chipboard
Surface treatment	Lacquered venér
Color	Light oak
Packaging dimensions and weight	
Package height(m)	1,570
Package width (m)	0,420
Package depth(m)	0,370
Package weight(kg)	32,000
Miscellaneous	
Suspension type	Justerbara upphängningsbeslag med väggskena
Opening function	Soft close

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.