

HIGH CABINET EDGE SMOKED OAK

Item number: 1590372

Edge from Hafa is a high cabinet in smoked oak with a real wood veneer finish. The cabinet features slim edges and a clean, modern form that creates a minimalist and elegant look in the bathroom. The door opens with a push-to-open function, giving a smooth front with no visible handles.

Inside, there are five shelves: Four height-adjustable glass shelves held securely in place, and one fixed wooden shelf.

The cabinet is delivered fully assembled and mounted easily on the wall. The door can be installed left- or right-handed to suit your bathroom. A mirror is fitted on the inside of the door. Power socket available as an option.

DETAILED INFORMATION

Item number	
NOBB	60941935
EAN	7330027183701
Standards and classifications	
Sunda Hus	No
ETIM	EC010013
Product dimensions and weight	
Width	400
Depth (mm)	250
Height (mm)	1550
Net weight (kg)	27
Left/right model	Vändbar

Material and surface treatment	
Main material	Chipboard
Front material	Chipboard
Body material	Chipboard
Surface treatment	Lacquered venér
Color	Smoked oak
Packaging dimensions and weight	
Package height(m)	0,310
Package width (m)	0,460
Package depth(m)	1,610
Package weight(kg)	33,500
Miscellaneous	
Suspension type	Justerbara upphängningsbeslag med väggskena
Opening function	Push-to-open

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.