

MIRROR CABINET GO BASIC 600 WHITE

Item number: 1580260

The Go Basic mirror cabinet is a modern and practical mirror cabinet with plenty of storage space. Soft closing double-sided mirrored doors with 125° opening angle. Prepared for installation of lighting on top and electrical box with electrical outlet inside. In the electrical box, electricity from the wall and lighting can easily be connected while the cabinet is up on the wall. The mirror cabinet is mounted on a rail on the wall with adjustable suspension fittings, making it easy for one person to install. Purchase the Go LED lamp (1267270 or 1267271) or Go lighting profile (1580262) and the electrical box with socket (1580261).

25 year WARRANTY

Quality

Listad i Svanens Husprodukt portal

DETAILED INFORMATION

Item number	
NOBB	60152925
RSK	8946600
EAN	7330027173481
Standards and classifications	
ETIM	EC011384
BVB id	173983
Product dimensions and weight	
Width	600
Depth (mm)	145
Height (mm)	650
Net weight (kg)	7,5

Material and surface treatment	
Main material	Chipboard, Mirror glass
Body material	Chipboard
Surface treatment	Melamine faced
Color	White
Packaging dimensions and weight	
Package height(m)	0,710
Package width (m)	0,660
Package depth(m)	0,200
Package weight(kg)	12,000
Miscellaneous	
Suspension type	Justerbara upphängningsbeslag med väggskena
Opening function	Soft close

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.