

UNDER CABINET EDGE WHITE 1000

Item number: 1590020

The Edge vanity unit in matt white from Hafa is a stylish choice with slim lines, mitred corners and exclusive materials. The well-considered design creates an elegant expression that enhances the entire bathroom. The integrated SmoothOpen™ system combines push-open and soft-close for smooth and quiet use.

The unit is delivered fully assembled with drawer mats that help keep things organised, add a considered feel to the interior and make cleaning easy. Complete with a worktop and a countertop basin, or with an inset washbasin to complete the overall look. Handles are available as an optional extra for those who want to customise the unit to suit their own style.

25 year WARRANTY

DETAILED INFORMATION

Item number	
NOBB	51456595
RSK	8906598
EAN	7330027103341
Stocked article	Yes
Standards and classifications	
Sunda Hus	No
Säker Vatten	Yes
ETIM	EC011382
Product dimensions and weight	
Width	1000
Depth (mm)	456
Height (mm)	450
Net weight (kg)	32

Material and surface treatment	
Main material	Chipboard, MDF
Front material	MDF
Body material	Chipboard
Surface treatment	Lacquered
Surface finish	Matt
Color	White
Packaging dimensions and weight	
Package height(m)	0,510
Package width (m)	0,515
Package depth(m)	1,060
Package weight(kg)	34,000
Miscellaneous	
Suspension type	Justerbara upphängningsbeslag med väggskena
Opening function	SmoothOpen

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.