



EDGE UNDER CABINET 1000 WHITE

Item number: 1590020

Basin vanity unit with SmoothOpen™ drawer system, a combination of push-open and soft-close in one. FlexStorage™, a flexible drawer divider in varnished solid oak; non-slip mats in the drawers to make cleaning easier are included. Reinforced with an aluminium frame on the front edge. Supplied pre-assembled. The top drawer has a U design, leaving space for the water trap. Add a freestanding washbasin in porcelain or glazed steel on a Silestone worktop or submerged porcelain washbasin and a PUM water trap designed for vanity units, 126 56 00. Prepared for both floor and wall drains. Adjustable hanging brackets. Drawer lighting, power socket and handles available as an option. Available in white and anthracite gray and in three different sizes 600/800/1000.



DETAILED INFORMATION

Item number		Material and surface treatment	
NOBB	51456595	Front material	Moist resistant MDF
RSK	8906598	Body material	Moisture resistant MDF
EAN	7330027103341	Surface treatment	Lacquered
Stocked article	Yes	Surface finish	Matt
Standards and classifications		Color	White
Säker Vatten	Yes	Packaging dimensions and weight	
ETIM	EC011382	Package height(m)	0,510
Product dimensions and weight		Package width (m)	0,515
Width	1000	Package depth(m)	1,060
Depth (mm)	456	Package weight(kg)	34,000
Height (mm)	450	Miscellaneous	
Net weight (kg)	32	Suspension type	Justerbara upphängningsbeslag med väggskena
		Opening function	SmoothOpen

CARE INSTRUCTIONS

In order to keep the furniture in good condition, it is important that you look after it. Our furniture is manufactured from materials with excellent moisture resistance but items should still not be exposed to too much water. Always wipe off any water on the furniture. The simplest way to clean your furniture is to use a moist cloth, perhaps with a little ordinary eco-friendly detergent. Avoid using any detergents and products containing abrasive agents, acids, ammonia, acetone or other chemicals (such as scouring powder, hairspray, hair dye, bleach, hair removal cream and nail varnish remover, etc.). If any of the above items should get on the furniture, they should be removed immediately in order to avoid damage. Avoid having any sharp objects near the furniture that might damage the outer surface.